



BOTTOM COVER INSIDE VIEW

POSSIBLE PCB FOOTPRINT

NOTES:

1. USE #3 X .250" OR M-2.5 SELF THREADING SCREWS TO MOUNT THE PCB TO HOUSING
2. RECOMMENDED HOUSING ASSEMBLY SCREW TORQUE SETTING TO OBTAIN IP65 RATING IS 5 IN-LBS
3. TO MAINTAIN IP65 RATING THE GASKET CAN ONLY BE USED ONCE; MUST BE REPLACED IF HOUSING IS OPENED.

COLOR	CODE #	PMS #	RAL #
ABS	1129	WARM GRAY #2	1013

PACNTEC[®]
1-610-361-4200

SODF6040-1.7-UD

VISIT **PACNTEC**[®]
ON THE WORLD WIDE WEB
www.pactecenclosures.com